

April 2014

ABB RVG200 For Food and Beverage Applications

Data recording in food and beverage processes
Obtaining a better picture of your production process using
ABB's RVG200 data recorder

A complete view of your food and beverage process data at your fingertips.



Introduction

ABB's RVG200 next generation paperless data recorder offers a host of additional features and functions, making it ideal for data recording in food and beverage production applications.

How can the RVG200 help?

Touchscreen technology for easy operation

Featuring touchscreen technology, the RVG200 makes it easier than ever to find the data you need. Intuitive icon-based menus and a 'swipeable' interface enable data to be quickly located and viewed in a variety of formats, including individual or grouped data in chart, bar graph or digital indicator displays.

Maximum ingress protection

The RVG200's entire front panel, including its media door, features NEMA 4X and IP66 levels of ingress protection, offering a highly effective safeguard against the high levels of moisture commonly found in food processing plants.

This same protection also enables the front panel of the recorder to withstand the rigours of hose downs during regular plant cleaning activities.

Batch recording for fast and detailed batch data

The RVG200's batch recording option provides a simple means of recording when a particular batch is started or finished.

Collected data can be reviewed using ABB's DataManagerPro analysis software, which provides a quick and simple way of retrieving batch data. With DataManagerPro, you can find the data you need by entering the batch number, searching by type or product or by specifying the time and date of processing.



| New Batch | |
|---|------------|
| Batch Number | BGD-568563 |
| Product | Peas |
| Container | Tin |
| Cycle Type | Standard |
| <input type="button" value="X"/> <input type="button" value="✓"/> | |

To read more information or to download the complete application note, please click [here](#).

Davis Controls Ltd.
2200 Bristol Circle
Oakville ON L6H 5R3
Tel: 800-701-7460 / 905 829-2000

Fax: 905-829-2630

www.daviscontrols.com

[Email Us](#)

