

What do our Magnetic Level Gauges Offer?

Our Magnetic Level Gauges with Local Indication and Point Level Switching or Continuous Output. Large brightly coloured indicating wafers are easy to read, even at a distance. The ideal solution where the risk of fluid leaking to the environment must be avoided. Eliminates maintenance associated with conventional glass gauges. Available with optional Magnetostrictive Linear Displacement Transducer for 4-20mA output.



The Klinger design uses patented edge magnetized molded ferrite wafers, which, provide excellent performance and reliability, even under the most arduous conditions. As the float rises or falls with the liquid, each wafer rotates 180 degrees and so presents a contrasting colour. Wafers above the float magnet show white, while those level and below the float magnet show red, providing an accurate indication of the level of liquid in the chamber.

