



*Happy Holidays  
From  
Davis Controls*

## **FLOWLINE®**

### **EchoPod DL14 1.25m Ultrasonic Multifunction Transmitter, Switch & Controller**

#### **Description:**

The general purpose, ultrasonic sensor provides non-contact level detection up to 49.2" (1.25m) with 4 SPST 60 VA 1A relays and a two-wire 4-20 mA level measurement output. Each relay can be configured on a single set point alarm or latched on two sets for automatic fill or empty in simplex or duplex control modes with fail-safe logic. The embedded controller can replace external control hardware. The sensor is well suited for a wide range of corrosive, sticky or dirty type media. EchoPod is broadly selected for small atmospheric day tank, skid or process vessel, lift station, IBC, drum and sump applications.



#### **Specifications:**

Range: 2" to 49.2" (1.25m)  
Signal output: 4-20 mA, two-wire  
Contact type: (4) SPST relays 1A  
Enclosure rating:  
Type 6P Process mount: 1" NPT (1" G)

#### **Also Available:**

- DL24 2.5m Ultrasonic Multi-Function Transmitter, Switch & Controller
- DS14.1 1.25m Ultrasonic Switch Controller with (4) Relays
- DX10 1.25m Ultrasonic Sensor with Voltage & Frequency Output
- DL10 1.25m Ultrasonic Transmitter with 4-20mA Output

**Davis Controls Limited**  
**2200 Bristol Circle, Oakville, Ontario, L6H 5R3**  
**1-800-701-7460**

[Email Us](#)