

## AUTOMATION SERIES

# CB40

## BELTED CURVE CONVEYORS

CB40 Conveyors guide product around a turn, maintaining the same orientation at both infeed and outfeed. Consistent product orientation ensures downstream operations receive product the same way each cycle.



## FEATURES AND BENEFITS

### POSITIVE SPROCKET DESIGN

To ensure positive movement, CB40 Conveyors are driven by a patented sprocket that engages followers embedded in the edge of the belt. The sprocket design eliminates the need for belt tracking and enables bi-directional running.



### SEAMLESS INTEGRATION

CB40 Conveyors are designed to transition product seamlessly with our AS40 family of conveyors. They feature the same brushless DC motors and integrated controllers, allowing them to easily integrate with existing controls.

### BOTTOM DRIVE GEARMOTOR

The unique bottom drive design of CB40 Conveyors ensures the motor stays below the center of the conveyor and out of the way, making it easy to integrate with other machinery.




### FAST CHANGEOVERS AND CLEANING

CB40 Conveyors can be removed quickly from their stands for cleaning. Extra conveyor beds are available to be swapped, allowing fast changeovers between products where cross-contamination could be an issue.



Includes stand and 5/8" fixed sides

All Metric Fasteners.



## APPLICATIONS

Automation & Robotics

Assembly

Automotive

Material Handling

Pharmacy & Medical

Packaging

Marking & Coding

CB40 | Automation Series



10 DAY LEAD TIME ON  
QUICK SHIP SIZES  
12" & 24"  
(6" & 18" also available)